

# ACROBATION PRE-LANGING SPARE PARTS

OPERATOR'S COPY

**Interior** 

**Door Feeder** 

**Jamb Routers** 

**Exterior** 

**Architectural** 

**Patio Door Line** 

**Entry Door Line** 

**Automatic Saws** 

**Pre-Fit Jamb** 

**Bi-fold** 







#### **About KVAL Machinery**

KVAL was started in the mid 1940's by AA Kvalheim. A Norwegian trained furniture maker, who turned to cabinetmaking and carpentry, and eventually machinery manufacturing after immigrating to the United States. One product produced in the mid 40's was a panel saw which helped expand the fledgling flush door industry that was developing around the Walled Lake, Michigan area. Early door sizing systems were supplied to companies like Young Door, Walled Lake, Arrow Door, and out on the west coast to Cal Wood Door.

In the mid 1950's, sons Andy and Irv Kvalheim joined in the business. As the company grew, so did the line of products. Door pre-hanging equipment was designed for distributors and high production equipment was designed for manufacturers producing pre-fit units. During the growth years of the 60's, the company continued as an innovator in the industry with automatic machines for jamb processing, casing trimmers and updated door sizers. As the 70's began, customers began demanding even more automation to cut labor costs and improve product quality. Kval responded with bifold door assembly and pre-hanging machines featuring fully automatic screw driving systems.

Today, Jerry, David, and Mark Kvalheim...the three grandsons of AA Kvalheim have joined the firm. The company family has also grown to include George Kameoka as head engineer, and Mark Smith as one of the managing partners.

KVAL products have continued to evolve and are now faster than ever, but are easier to set up, and produce higher quality doors than ever before. Recent technical innovations include CNC controls and the complete replacement of air logic control systems with solid state programmable controllers. Fully automatic positioning and sequencing for door and jamb equipment. Digital readouts with touchscreen controls to guarantee accurate setup and operation. When looking for quality door, jamb, casing, and related machines, look to the leader in the industry for over six decades!

Look to KVAL!!!



© KVAL Inc. All rights reserved

This document may not be copied, photocopied, reproduced, transmitted, or translated in any form or for any purpose without the express written consent of KVAL Inc.

KVAL Inc. reserved the rights, without notice, to change design and construction of any products.

Price are subject to change without notice.

Errors in description, photography, or typographical errors are subject to correction.

Printed in the United States of America Published on 10/1/2014

Acrobat



#### **Acrobat**

KVAL's innovative Acrobat Metal Door Pre-Hanging Machine is designed for inserting door lights into metal doors and for attaching brick moulding and assembling door frame.

This design eliminates manual lifting of doors during the assembly process. Doors are rolled into the machine on non-marking wheels. Lights are inserted from the bottom up simply by depressing a foot switch. The door is then raised to spin over in order to assemble the door frame and attach exterior casing. The assembled door unit is then rolled onto the tilt arm and raised to a vertical position for easy off-loading.

Pneumatic hand tools can be attached to air supplies underneath the light table. Acro Bins, surrounding the under-edges of the Acrobat, conveniently hold hardware and supplies.

#### DOOR SIZE SPECIFICATIONS

Door height: 6'-8' to 8'-0" Door width: 2'-6" to 3'-0" Door thickness: 1-3/4"

Maximum door weight 100 lbs.

#### **SPECIFICATIONS**

Footprint Size: 19'-1"x 3'10"







#### **Standard**

#### **Mechanical**



Spring 1-3/16-OD X 7/8-ID X 12 Long, .162 Wire Hooked Ends

KVAL P/N: 381200H



Spring,1-1/4" OD X 7/8" ID X 12" Long,.162 Wire,Double Loop Each End

**KVAL P/N: 401200LD** 



Mfg, Acrobat, Door Stop, Delrin, 3/4 x 1-1/2 x 8-15/16

KVAL P/N: 45-00-F16



Mfg, Acrobat, Lift Adjustable End Pivot Plate Pad, Green Belting, 2-1/2" X 7"

**KVAL P/N: 45-00-HD** 



Screw Gun Holder Mount Assembly, Includes spiral wrap encasement & (2) 1/4-20 X 5/8LG FH

KVAL P/N: 536A



Flanged Wheel Bearing, Regular Duty, 1/2 ID - 1 3/8 OD, Flange Width 7/16, Flange OD 1 1/2.

**KVAL P/N: BAI150050** 



Bearing, 1" Closed Super Linear Pillow Block

**KVAL P/N: INASPBC160** 



Chain, Connecting Link, 50 Chain

**KVAL P/N: LIN500001** 



Fastener, Washer, 1-3/8" I.D. 1-7/8"O.D., .025,

Steel

KVAL P/N: MC3088A419



Handle, Zinc-Plated Steel Weld-in Pull Pin Non Locking With T-Handle, 1/2" Pin Dia., 1-1/2" Barrel L

KVAL P/N: MC90222A116



Chrome Steel Ball, 1/2" Dia.

**KVAL P/N: MC9528K24** 



Pad, 60 Duro Green, 3-15/16 X 1-7/8 Molded with Steel Insert.



Pad,Aluminum,6" Dia,5/8 Thick,3/8 NC Thread

KVAL P/N: P961012CA

KVAL P/N: P633006-N



Split Collar, One Piece, 1-1/4" Dia., Steel

KVAL P/N: SC120F



Bearing 5203ZZ, 17mm Bore, 40mm OD X 17.5 Width

**KVAL P/N: SNR5203ZZ** 



Cam Follower, 7/8 Dia, With Stud

**KVAL P/N: TORCRS14** 



Roller Green Polytube 3 Dia X 3/4 Wide 1-3/8-ID 60 Duro

**KVAL P/N: WESPT7612** 



# ACROBAT

#### **Standard**

#### **Pneumatic**



Cylinder, Advance, 300 X 9"

KVAL P/N: ADV300A22



Safety Exhaust Ball Valves; 1/4" NPT

**KVAL P/N: BBVALVE04** 



Safety Exhaust Ball Valves; 1/2" NPT

KVAL P/N: BBVALVE08



Cylinder, Bimba 242DP 2" Double Acting Rear Pivot Mount 1-3/4 Bore.

**KVAL P/N: BIM242DP** 



Cylinder, Bimba 242DXDE 2" Double Acting Double End Rod Mount 1-3/4 Bore.

**KVAL P/N: BIM242DXD** 



Cylinder, Bimba 243DP 3" Double Acting Rear Pivot Double End Mount 1-3/4 Bore.

**KVAL P/N: BIM243DP** 



Cylinder, Bimba 3120DXP, 20" Stroke, Double Acting Rear Pivot Mount, 2" Bore.

KVAL P/N: BIM3120DXP



Cylinder, Bimba 3121DXP, 21" Stroke, Double Acting Rear Pivot Mount, 2" Bore.

**KVAL P/N: BIM3121DXP** 



Cylinder, Bimba 313DXP, 3" Stroke, Double Acting Rear Pivot Mount, 2" Bore.

KVAL P/N: **BIM313DXP** 



Cylinder Hardware, Bimba 240 Foot Mount Bracket 1.037 Bore, 3" Long Slotted Base

**KVAL P/N: BIMC1337** 



Cylinder Hardware, Bimba, Clevis, 240,310,050,1/2-20 National Fine Thread 1.69 Long .38 Pin.

**KVAL P/N: BIMD2313** 



Cylinder, Bimba, Hardware, 2" & 2-1/2" Bore Cylinder, 2-Piece Pivot Bracket .375 Pin 3.00 Long Slotted Base.

**KVAL P/N: BIMD620** 



Cylinder, Bimba, Hardware, 2-Piece Pivot Bracket .375 Pin 2.88 Long Slotted Base

**KVAL P/N: BIMD6201** 



Air Hose, 2 Bonded Coiled Hose, 6 FT, Tube .375 OD X .245 ID, With 8" Tails

**KVAL P/N: BUCM31508** 



Pneumatic Quick Coupling, 1/4", Female Pipe Thread

**KVAL P/N: DYNASW340A** 



Directional Control Valve, Fabco 18 Series, PMD-4,1/8" NPT, 4-WAY, Detented(Push-Pull), Panel Mount Button

**KVÁL P/N: FAB18PMD4** 







#### **Standard**

#### **Pneumatic**



Valve, Fabco, Repair Kit, 1800-944, Spool With O-Rings, For Push Pull Valve

**KVAL P/N: FAB18PMD4-RK** 



Regulator, 1/4" Mini With Check Valve (1/8" Body with 1/4" Ports)

KVAL P/N: SMC20001R



Regulator, Bracket, 1/4" Mini

KVAL P/N: SMC20001Y



Filter, 1/2" With Auto Drain, SMC, AF40-N04D-Z

KVAL P/N: SMC40004F



Speed Controller, Standard, 1/4" Right Angle, 1/4 NPT,Metal Body Elbow Style

**KVAL P/N: SMCAS2102** 



Speed Controller, One-touch Fitting, 1/4 NPT - 1/4" OD, Elbow & Universal Types, NAS2201F-N02-07S

**KVAL P/N: SMCAS2201F2** 



Pressure Gauge, SMC, K40, 1/8 NPT Thread, 160 PSI

KVAL P/N: SMCK10



Valve, VQC4100-5 or VQC4101-5 SMC Valve Without Base, Single Acting 24VDC.

**KVAL P/N: SMCVQC4100-5** 



Valve, VQC4200-5 SMC Valve Without Base, Double Acting, 24VDC

**KVAL P/N: SMCVQC4200-5** 

### To see our full line of products,

go to kvalinc.com and type in

Electrical



# ACROBAT

#### **Standard**

#### **Electrical**



End Plate For Grounding Terminal Block, Entrelec 01036221

KVAL P/N: 01036221



Terminal Block, 6mm, 30A, Grey, Screw 30A/600V Max., Accepts 24-10 AWG Wire M4/6. Screw Terminal

KVAL P/N: 011511607



Grounding Terminal Block Entrelec, Green/ Yellow, 24-10 AWG, 6mm Width Electrically Connected to Rail, 016580901

KVAL P/N: 016580901



Terminal End Section, Entrelec 11836816

KVAL P/N: 11836816



Twin Foot Switch Linemaster 632-S

**KVAL P/N: 632S-TWIN** 



Sensor, Fixed Range, 2" Fixed Field, 24 Volts

DC, 18mm Dia.

**KVAL P/N: DIFUSEFF2-M12** 



PLC, IDEC MicroSmart, 24 I/O PLC

**KVAL P/N: FC4A-C24R2** 



Cord M12 Conn 4 Wire DC 5 Meters

KVAL P/N: M12-4PIN-DC-5M



Disconnect Shaft Stromburg 3/16" X 3/16" X

10-1/2" OAL

**KVAL P/N: OETLZS49** 



Pistol Handle, Red/ Black, Nema 1, 3R, 12 Accepts 6mm SQ Shaft, 65mm Handle Padlockable

KVAL P/N: OHB65J6



Disconnect Switch, 80 Amp, 3 Poles, ABB, OT80F3, 1SCA105798R1001

**KVAL P/N: OT80F3** 



Disconnect, Neutral For OT63E3

**KVAL P/N: OTPN63EP** 



Disconnect 6mm Shaft, 290mm long.

**KVAL P/N: OXP6X290** 



# **Option B - Outswing**




Mfg, Acrobat/Acro, Opt-B, Roller for Outswing Door Support, Delrin, 2" Dia. X 3"

KVAL P/N: 10-0B-XC


go to kvalinc.com and type in

## **Notes**





## **Notes**





Billing Address Company: Your name: Address: City/State/Zip: Phone:		Cor Yo Ad Cit	ipping Address mpany: ur name: dress: y/State/Zip: one:		
Quantity Part Numb	er	Item Descri	iption	Unit Cost	Total Cost
<b>Shipping Preference</b>				Total	\$
UPS Next Day Early AM UPS Next Day UPS 2nd Day	ernight vernight		Sales Tax and Shipping Charges to be determined		
UPS 2nd Day UPS 3 Day Select UPS Ground Common Carrier  FedEx 2nd Day FedEx Express Saver FedEx International Prio FedEx International Star				Thanks for your order! We appreciate your business!	
	·				
Payment Method C.O.D (Collect on Delivery) Established Acce		ed Account ( PO	#)	Cred	lit Card*
Card Number:Cardholder's Name:	*If Credit Card is chosen,VISA MasterCar	rd American	he information below. Express		
Expiration Date: Card Validation Value (CVV): Signature	(VISA/MasterCard - 3 c	digit/American Expres.	s - 4 digit)		

#### **Parts Department**

Monday thru Thursday 6:00 a.m. to 4:00 p.m. Pacific Time

> Friday 6:00 a.m. to 1:00 p.m.

Email: orders@kvalinc.com

WWW.KVALINC.COM





Published on 10/1/2014